GREEN MADE EASY

CHIMSOC INSTRUCTIONS AND WARRANTY INFORMATION

Positioning

Your Chimsoc® should be positioned inside your chimney stack. It's normally located about 300mm up the stack itself, but can be positioned anywhere where there are two parallel sides in the chimney stack, and where there are no sharp protrusions.

Installing Your Chimsoc®

Firstly, attach the inflation hose to the end of the valve on the Chimsoc®. Open the valve and part-inflate the Chimsoc®.

Offer the Chimsoc® into position in the chimney stack, and complete inflation. Close the Chimsoc® valve. The inflation hose can then be removed if required.

Topping Up

After re-installing your Chimsoc®, it is a good idea to Top Up this is especially the case when using lung air for inflation. The reason for this is that lung air is warm. As it cools, it contracts. One way to avoid this is to use a pump for inflation.

Tethering

In some chimneys with high draw, there is a danger that your Chimsoc® could be drawn up the chimney. This is especially true if the Chimsoc® is not topped up with air on a regular basis. We recommend that, in these chimneys, that you tether your Chimsoc® to the fire grate or something similar to prevent this happening.

Ventilation

Chimney stacks require a small amount of ventilation, to avoid the risk of damp build up. Your Chimsoc® has been designed with a curve at one end to help achieve this.

Removing

Place a sheet of paper or cloth over your fire (your Chimsoc® may have collected some dust or debris on the top side).

Open the valve and allow some of the air out. Carefully remove the Chimsoc®.

Important

It is a good idea to use safety eyewear when re-installing your Chimsoc®

The Chimsoc® can only be installed in a completely cold chimney stack.

The Chimsoc® may puncture if inflated against sharp protrusions in your chimney stack. The Chimsoc® is designed for use in your chimney stack to stop chimney draughts. No responsibility will be accepted for damage caused by failure to remove your Chimsoc prior to lighting your fire, misuse of the product, or where our instructions have not been fully adhered to.

This is a plastic product. Please keep it away from children

Guarantee

90 Day Faulty or Damaged Guarantee

The Sale of Goods Act 1979 (as amended) states that all products supplied by us should be of "satisfactory quality", "as described", and "fit for purpose". If an item supplied by us doesn't conform to these criteria, you have the right to request money back within a "reasonable time".

1 Year Replacement of Product Guarantee

In addition to the above guarantees, the Chimsoc is offered with a 1 year replacement of product guarantee (except for normal wear and tear). Should you Chimsoc fail within this period, please send it back to us for testing. Should we find that the problem is not caused by normal wear and tear, we will replace your Chimsoc for a new one.

*Should you require replacement of a faulty product as described in the Guarantee Information above please contact us below.




1300 658 069

GREEN MADE EASY PTY LTD Building 10, Level 3 658 Church St Richmond VIC 3121



GREEN MADE EASY

CHIMSOC INSTRUCTIONS AND WARRANTY INFORMATION






Your Chimsoc® contains the following items:-

1 x Chimsoc® 1 x Reminder Disc

1 x Inflation Hose 1 x Instructions



No Chimsoc®



1300 658 069

WWW.GREENMADEEASY.COM.AU